


# Installation Manual

HONDA CR-V 5DR  
HON-CRV-5-X



## COMPONENTS INCLUDED





|                                                                                  |                                                                                   |                                                                                   |                                                                                    |
|----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
|  |  |  |  |
| X2                                                                               | X2                                                                                | X1                                                                                | X1                                                                                 |



# Installation

HONDA CR-V 5DR

HON-CRV-5-X



# Installation

HONDA CR-V 5DR

HON-CRV-5-X



# Installation

HONDA CR-V 5DR

HON-CRV-5-X



# Installation

**HONDA CR-V 5DR**

**HON-CRV-5-X**

